

EMERGENCY EYE WASH STATION

Wall mounted eye wash station with two spray heads and yellow ABS plastic bowl. Provides an aerated spray at low pressure for washing the face and eyes of the injured person. Spray heads feature dust covers that float off when water flow is initiated. Large lever opens the valve to initiate the water flow and the valve remains open until it is manually closed. Intended for use in laboratories in industry, schools or universities. Requires a mains or emergency feed, preferably drinking water, minimum pressure 2 bar, 3/4" connection. Eye wash should be positioned in an easily accessible place, no more than 10 seconds away from any potential hazard.

C59-5320 Emergency Eye Wash Station



C59-5320

EMERGENCY SHOWER AND EYE WASH POINT

Free standing shower unit with eye wash point. Shower has yellow ABS head, provides a drenching shower automatically when the operating lever is pushed and the valve stays open until it is manually closed. Eye wash point has two spray heads and yellow ABS plastic bowl, provides an aerated spray at low pressure for washing the face and eyes of the injured person. Eye wash spray heads feature dust covers that float off when water flow is initiated, operated by a large lever which opens the valve to initiate the water flow and the valve remains open until it is manually closed. Intended for use in laboratories in industry, schools or universities. Requires a mains or emergency feed, preferably drinking water, minimum pressure 2 bar, 1 1/4" connection. Should be positioned in an easily accessible place, no more than 10 seconds away from any potential hazard. Overall height 2.1m

C59-5340 Emergency Shower and Eye Wash Point



C59-5340

FIRE EXTINGUISHERS

FIRE EXTINGUISHER, CO₂

CO₂ fire extinguisher for use on flammable liquid and electrical fires. Capacity 2kg.

C59-5410 Fire Extinguisher, CO₂



C59-5410



C59-5460

FIRE EXTINGUISHER, DRY POWDER

An all-purpose powder extinguisher suitable for multi-risk areas. Capacity 2kg.

C59-5460 Fire Extinguisher, Dry Powder

FIRE BLANKET

Glass fibre blanket, for wall mounting.

C59-5740 Fire Blanket, 4' x 4', Wall Mounting



C59-5740